


PARTS LIST

PARTS

1. Head
2. Body and control box
3. Lower frame pole
4. Middle frame Pole
5. Upper frame Pole
6. Metal base
7. Metal base with frame hole
8. 6V 2A Adapter
9. Frame pole cover
10. 5 lb Empty Sand Bag Weights



CARE AND STORAGE INSTRUCTIONS

When the product not in use, store in its original packing after it is completely dry.
Keep away from heat.


Please read all instructions carefully before assembling. Save this instruction sheet for future reference.

WARNING


This item is not a toy and should be used for decoration only. This item contains small parts that can be a choking hazard. Keep all plastic and wire parts away from children. Recommended for ages 14 and up.

1. Please use the adapter supplied by manufacturer.
2. Please assemble item according to instructions. Connect all wires according to matching color.
3. Children should be supervised by adults. Item should not be grabbed, as it becomes a tipping hazard. Keep all away from the adapter, as it heats up during operation.
4. This item contains Polyvinyl Chloride (PVC).
5. Colors, style and contents may vary slightly from those shown on the package.


ASSEMBLY INSTRUCTIONS



1
Insert 4 AA batteries (not included) into the battery compartment located on the back of the BODY AND CONTROL BOX.




2
Snap lock the HEAD onto the BODY AND CONTROL BOX.
(Match H to H)



3
Connect the wire from BODY AND CONTROL BOX to the wire located on the HEAD.
(Match G to G)




4
Connect the hook and loop fasteners located on the fabric on the underside of the HEAD.




5
Connect UPPER POLE to the BODY AND CONTROL BOX.
(Match F to F)

FOR HEIGHT RESTRICTED AREAS SKIP TO STEP 7.




6
Connect MIDDLE POLE to the UPPER POLE.
(Match E to E)

REMOVE MIDDLE POLE FOR HEIGHT RESTRICTED AREAS.




7
Snap lock METAL BASE to METAL BASE WITH FRAME HOLE.
(Match A to A)

(Match B to B)




8
Snap lock LOWER FRAME POLE onto METAL BASE WITH FRAME HOLE.
(Match C to C)

(Match C to C)




9
Slide the FRAME POLE COVER over the LOWER FRAME POLE.

ASSISTANCE RECOMMENDED FOR NEXT STEP.




10
Using assistance or two hands, hold/SUPPORT the UPPER AND MIDDLE FRAME POLES and carefully lower the HEAD and BODY.

Snap lock the MIDDLE FRAME POLE TO THE LOWER FRAME POLE.
(Match D to D)



11
Pull the FRAME POLE COVER up and over the two metal hooks located under the CONTROL BOX located on the back of the BODY AND CONTROL BOX.




12
For additional weight on the METAL BASE, fill SAND BAG WEIGHTS to their 5lb capacity.

Secure both SAND BAG WEIGHTS to the metal hooks to secure additional weight on the METAL BASE.

ASSEMBLY INSTRUCTIONS

OPTIONAL 7 FOOT ASSEMBLY




Plug in the 6V 2A ADAPTER (included) into the CONTROL BOX located on the back of the BODY.

Turn the switch to the ON position to activate the item. Move in front of the item to activate. Turn item OFF when not in use.




* NOTE: A human activated sensor detects the human infrared signature and must be uncovered and facing forward to trigger this item.

Make sure the human activated sensor located on the front of the item is facing forward, and not blocked by any fabric.



Secure the hook and loop fastener located on the back fabric panel around the FRAME POLE COVER and FRAME POLES. Secure the FABRIC POLE COVER hook and loop (Qty 4) to the METAL BASE to complete setup.



For height restricted areas, you MUST remove the UPPER FRAME POLE to reduce the item height. Connect the BODY AND CONTROL BOX to the MIDDLE FRAME POLE. (Connect E to F)

Proceed to step 11 to complete setup.

OPTIONAL FOOTPAD SET UP

FOOTPAD IS NOT INCLUDED. MUST BE PURCHASED SEPARATELY.


1. Insert the cable from optional footpad into the jack labeled FOOTPAD on the CONTROL BOX.
2. Place the switch in the FOOTPAD position to enable FOOTPAD activation.
3. Step on the FOOTPAD to activate the scary sequence!



OPTIONAL EXTERNAL SPEAKER SET UP

FOOTPAD IS NOT INCLUDED. MUST BE PURCHASED SEPARATELY.

1. Connect the wire from your external speaker to the jack labeled SPEAKER JACK on the control box.
2. Adjust Volume knob to desired level.






Warnings

- This product is for decoration only and is not a toy. Small parts and choking hazard. Use caution with children under the age of 14.
- Do not position the decoration near candles, sources of heat, or in direct sunlight.
- The decoration cannot be connected to the power supply directly.
- Decoration should be on a level, stable surface to prevent it from falling over.
- This product is fragile and should be assembled with care.
- Surface washable only.
- Please follow the steps and requirements specified in the instruction to ensure safety and reliability during the installation.

Battery Diagram



BATTERY INSTRUCTIONS AND CAUTIONS

Battery installation and removal should be performed by an adult.
Remove batteries when not in use.
Use only batteries recommended in the instructions.
Do not mix new and used batteries.
Do not mix alkaline, carbon-zinc, nickel-cadmium, rechargeable or different types of batteries.
Be mindful to insert batteries with the correct polarity (+/-) as indicated.
Remove all exhausted batteries.
Rechargeable batteries are only to be charged under adult supervision.
Rechargeable batteries are to be removed from the item before being charged.
Non-rechargeable batteries are not to be recharged.
The supply terminals are not to be short-circuited.
Always dispose of exhausted batteries properly.
Do NOT dispose of batteries in fire, they may leak or explode.

Warning! This item is not a toy. For decoration only. Small parts, choking hazard. This product is intended for use by persons 15 years of age and older. Not intended for use by children ages 14 years and younger.

WARNING

DO NOT TURN ITEM ON UNTIL YOU HAVE COMPLETELY FINISHED ASSEMBLY.

STAY CLEAR OF ITEM WHILE OPERATING.

DO NOT PLACE ITEM ON UNEVEN GROUND.

DO NOT PLACE WEIGHT ON ITEM WHILE IN OPERATION.

Storage tips: We suggest saving the carton for storing your figurine. Store in a cool, dry area where the temperature does not exceed 100° F.

Requires 4AA batteries (not included)
ALL NEW MATERIALS:
METAL, FOAM, PLASTIC, POLYESTER
Surface washable only.

SMART PHONE SCAN
SETUP VIDEO

