#5267886

HAUNTED LIVING®

# 11-IN POP-UP PUMPKIN



**INDOOR USE**



**(3) AA BATTERIES REQUIRED (INCLUDED)**

Actual: 7.87 in x 7.87 in x 11 in
Real: 19.98 cm x 19.98 cm x 27.94 cm

Distributed by
Distribuido por:
Lowe's Home Centers LLC
1000 Lowe's Blvd.
Mooresville, NC 28117
888-251-1006

**MADE IN CHINA**
**HECHO EN CHINA**




0124
Item | Artículo #5267886




Model | Modelo #61085
LW300256-012024

TEKKY and the logo design are trademarks of JCW Investments, Inc., d/b/a Tekky, and used under license.
TEKKY y el diseño del logotipo son marcas comerciales de JCW Investments, Inc.en representación de Tekky, y se utilizan bajo licencia.

⚠ WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov.

HAUNTED LIVING and logo design are trademarks or registered trademarks of LF, LLC. All rights reserved.
HAUNTED LIVING y el diseño del logotipo son marcas comerciales o marcas registradas de LF, LLC.
Todos los derechos reservados.

**INSTRUCTIONS:**
KEEP ALL PLASTIC AND WIRE PARTS AWAY FROM CHILDREN.

1. Carefully remove and discard "Try Me" wire and packaging.
2. Use a small Phillips/crosshead screwdriver to open the item's battery compartment located on the bottom of 11-in Pop-Up Pumpkin.
3. Place 3 new AA alkaline batteries into the battery compartment and replace cover.
4. Place power switch located on the bottom of item to the "ON" position to operate in sound and motion activation mode.
5. Make a loud sound (clap) or wave hand in front of the 11-in Pop-Up Pumpkin to activate the scary sequence!

**INSTRUCCIONES:**
MANTENGA TODAS LAS PIEZAS DE PLÁSTICO Y ALAMBRE FUERA DEL ALCANCE DE LOS NIÑOS.

1. Retire y deseche con cuidado el cable "Pruébeme" y el empaque.
2. Utilice un destornillador Phillips para abrir el compartimiento de la batería del artículo que se ubica en la parte inferior de la CALABAZA EMERGENTE DE 27.94 cm.
3. Coloque 3 baterías alcalinas nuevas en el compartiymiento de la batería y reemplace la tapa.
4. Coloque el interruptor de encendido que se ubica en la parte inferior del artículo en la posición "ON" para hacer funcionar el sonido y el modo de activación de movimiento.
5. Haga un sonido alto (una palmada) o agite la mano frente a la CALABAZA EMERGENTE DE 27.94 cm para activar la secuencia espeluznante!

**NOTE:** Leave switch in the "OFF" position when not in use.
**NOTA:** deje el interruptor en la posición "OFF" cuando no esté en uso.

**BATTERY INFORMATION:**

1. Contains (3) AA 1.5-volt alkaline batteries. Batteries are not rechargeable.
2. Battery installation and removal should be performed by an adult. Batteries are harmful if swallowed. Keep away from young children.
3. Remove batteries when not in use.
4. Use only batteries recommended in the instructions.
5. Do not mix new and used batteries.
6. Do not mix alkaline, carbon-zinc, nickel-cadmium, rechargeable or different types of batteries.
7. Be mindful to insert batteries with the correct polarity (+/-) as indicated.
8. Remove all exhausted batteries.
9. Rechargeable batteries are only to be charged under adult supervision.
10. Rechargeable batteries are to be removed from the item before being charged.
11. Non-rechargeable batteries are not to be recharged.
12. The supply terminals are not to be short-circuited.
13. Always dispose of exhausted batteries properly.
14. DO NOT dispose of batteries in fire, they may leak or explode.