

ANIMATED DEVEILED EGGS™

Please read instructions carefully before use.
Retain for future reference.

OPERATING INSTRUCTIONS:

KEEP ALL PLASTIC AND WIRE PARTS AWAY FROM CHILDREN.

1. Carefully remove and discard "TRY ME" wire and packaging. Retain the hang tag/instructions for future reference.
2. Use a small Phillips/crosshead screwdriver (not included) to open the battery compartment located on bottom of item.
3. Place 3 brand new "AA" alkaline batteries into the battery compartment and replace battery compartment cover.
4. Place the power switch, located on bottom of item, to the "ON" position to operate the item in SOUND AND MOTION activation mode. Make a loud sound (clap) or wave your hand in front of ANIMATED DEVEILED EGGS™ to "hatch" the silly sequence!

NOTE: Keep switch in the "OFF" position when not in use.

Includes: (1) ANIMATED DEVEILED EGGS™ decoration.
INDOOR USE. Display on level surface.
Surface washable only. Keep away from open flame.

TekkyDesign.com

⚠ WARNING! CHOKING HAZARD — small parts.

This item is not a toy. For decoration only. This product is intended for use by persons 15 years of age and older. Not intended for use by children 14 years of age and younger.


BATTERY INSTRUCTIONS:

- Contains (3) AA 1.5-volt alkaline batteries. Batteries are not rechargeable.
- Battery installation and removal should be performed by an adult.
- Batteries are harmful if swallowed. Keep away from young children.
- Remove batteries when not in use.
- Use only batteries recommended in the instructions.
- Do not mix new and used batteries.
- Do not mix alkaline, carbon-zinc, nickel-cadmium, rechargeable or different types of batteries.
- Be mindful to insert batteries with the correct polarity (+/-) as indicated.
- Remove all exhausted batteries.
- Rechargeable batteries are only to be charged under adult supervision.
- Rechargeable batteries are to be removed from the item before being charged.

3AA

BATTERIES REQUIRED

Batteries included for
"try me" demo
purposes only.



- Non-rechargeable batteries are not to be recharged.
- The supply terminals are not to be short-circuited.
- Always dispose of exhausted batteries properly.
- DO NOT dispose of batteries in fire, they may leak or explode.

⚠ WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov