LIGHT ACTIVATED! SCARE EVERYONE! HIDE IT ANYWHERE!

HIDING PLACE EXAMPLES:







CABINET

FRIDGE



HIDE IT IN A CABINET, DRAWER, PURSE, ANY DARK ROOM, Tool Box, Bathroom, Fridge, etc...get creative!

OPERATING INSTRUCTIONS

- 1. REMOVE LIGHT-DUTY BATTERIES AND Replace with Fresh New Alkaline Cells.
- 2. FIND A SUITABLE DARK HIDING PLACE.
- 3. USE SUCTION CUP TO ADHERE THE HIDDEN SCREAMER™ TO A FLAT, SMOOTH SURFACE. (WET SUCTION CUP TO ADHERE BETTER)
- 4. TURN SWITCH ON THE BACK OF THE Screamer to the "ON" Position.
- 5. WHEN THE SCREAMER SEES LIGHT, IT LETS OUT A LOUD, FRIGHTENING SCREAM!

BATTERY INSTRUCTIONS + CAUTIONS

- DO NOT MIX OLD AND NEW BATTERIES.
- DO NOT MIX ALKALINE, STANDARD (Carbon-Zinc) or Rechargeable (Nickel-Cadmium) Batteries.
- DO NOT DISPOSE OF BATTERIES IN FIRE, They may leak or explode.



REQUIRES 3 LR44/357 BUTTON CELL BATTERIES (Included for demo purposes only.)

AGES 15+

SURFACE WASHABLE ONLY. All New Materials: Plastic

\Lambda WARNING

CHOKING HAZARD – Small parts. This item is not a toy. For decoration only. Intended for use by persons 15 years of age and older. Not intended for use by children 14 years of age and younger.

> Item #58527. HIDDEN SCREAMRER* –SUGAR SKULL HIDDEN SCREAMERS* is a trademark of TEKKY. COPYRIGHT © 2011-2021 Tekky. ALL RICHTS RESERVED. MADE IN CHINA