

Scary sound & light reveal an awful fright!

revelan un susto terrible!



Batteries included for "Try Me" demo purposes only pilas "AA" x DC 1.5Vrequeric

Incluye pilas para demostración

It's tea time...for terror! Beware! This little monster will show you her true face!

MOTION ACTIVATED

OPERATING INSTRUCTIONS

KEEP ALL PLASTIC AND WIRE PARTS AWAY FROM CHILDREN

- Carefully remove and discard the "Try Me" wire and packaging.
- Replace demo batteries with 3 brand new "AA" alkaline batteries into the battery compartment located on bottom of TEA TIME TERROR™.
- Place switch on the module to the "ON" position.
 Wave your hand in front of TEA TIME TERROR™ to activate scary sequence!
 - NOTE: Keep the switch in the "OFF" position when not in use.

SURFACE WASHABLE ONLY. All new materials: plastic, fabric, wire. Item #59528 TEA TIME TERROR™ is a trademark of Tekky. Copyright © 2021 Tekky. All Rights Reserved. MADE IN CHINA Manufactured for. Tekky. Orland Park, IL 60467 USA **TekkyDesign.com**

BATTERY INSTRUCTIONS AND CAUTIONS

- Battery installation and removal should be performed by an adult.
- Batteries are harmful if swallowed, so keep away from young children.
- Remove batteries when not in use.
 Use only batteries recommended in the instructions.
- Do not mix new and used batteries.
- Do not mix alkaline, carbon-zinc, nickel-cadmium, rechargeable or different types of batteries.
- Be mindful to insert batteries with the correct polarity (+/-) as indicated.
- Remove all exhausted batteries
- Rechargeable batteries are only to be charged under adult supervision.
- Rechargeable batteries are to be removed from the item before being charged.
- Non-rechargeable batteries are not to be recharged.
- The supply terminals are not to be short-circuited.
- Always dispose of exhausted batteries properly.
- Do NOT dispose of batteries in fire, they may leak or explode.

THIS ITEM IS NOT A TOY. FOR DECORATION PURPOSES ONLY.